



136G7369 🛽

MCD60086BT7S1X20CV2

This product is not available in this store. Please contact your local Customer Service Center. **Customer Service Center** [조

MCD60086BT7S1X20CV2

MCD60086BT751X20CV2 VLT® Soft Starter MCD 600 With Int. Bypass Contactor 86 A, Three phase 380-690 V AC Frame size 1, IP20 Control Voltage: 110~120 VAC or 220~240 VAC Other options according to Model code

Model code: MCD60086BT7S1X20CV2

VLT* Soft Starter MCD 600 is a total motor starting solution.
Current transformers measure motor current and provide feedback for controlled motor ramp profiles.
Adaptive Acceleration Control (AAC) automatically employs the best starting and stopping profile for the application.
Emergency mode and Pump clean function are standard features.
The optional remote control panel adds more functionality, such as the Start/Stop buttons, and quick jump buttons to menu options.
VLT* Soft Starter MCD 600 is available in three enclosure sizes: S1, S2 and S3
S1: IP20 with built-in bypass contactor (20–129 A)
S2: IP00 either with built-in bypass or non-bypass (144 –579 A).
S3: IP00 with built-in bypass, non-bypass or external bypass

(590-1250 A)

To achieve protection rating IP20 on connections, order the Finger Guard Kit as an accessory.

PRODUCT DETAILS

	6.1 kg
	5.5 kg
	17.5891
	5710108638542
0001	No grouping
RIES	
GLBL	Global (Standard)
MCD	MCD Soft Starter series
6	600 Series
0086	86 A
В	With Int. Bypass Contactor
Т	Three phase
7	Three phase 380-690 V AC
S1	Frame size 1
Х	Reserved
	RIES GLBL MCD 6 0086 B T T 7 S1

Product Detail | MCD60086BT7S1X20CV2



PRODUCT DETAILS

IP Rating	20	IP20	
Control Voltage	CV2	110~120 VAC or 220~240 VAC	
Typecode Part 1		MCD60086BT7S1X20CV2	
Product Catalog	NO_VIEW	NO VIEW	
Modelcode01		MCD60086BT7S1X20CV2	
Calculated Gross Weight [kg]		6.1	
Calculated Net Weight [kg]		5.5	
Material Gross Weight		6.1	
Material Net Weight		5.5	
Plant from Orderline		B901	
Vendor	ERR01	Cannot Determine Vendor	
Recommended Factory	ERR01	Cannot Determine Vendor	

For Documents, Software, Visuals and more information, please use this link to visit the product page on Danfoss Product Store 🖄

ories	
	175G0131 MCD 600 Ethernet/IP MCD 600 Ethernet/IP supports network communication via easy-to-install communication expansion cards. Each communication card includes a remote LCP 601 connector port.
ŀ	175G0127 MCD 600 Modbus RTU MCD 600 Modbus RTU supports network communication via easy-to-install communication expansion cards. Each communication card includes a remote LCP 601 connector port.
Į	175G0128 MCD 600 Profibus MCD 600 Profibus supports network communication via easy-to-install communication expansion cards. Each communication card includes a remote LCP 601 connector port.
J	175G0129 MCD 600 Devicenet MCD 600 Devicenet supports network communication via easy-to-install communication expansion cards. Each communication card includes a remote LCP 601 connector port.

For more information, please use this link to visit the product page on Danfoss Product Store 🗈



	175G0130 MCD 600 Modbus TCP MCD 600 Modbus TCP supports network communication via easy-to-install communication expansion cards. Each communication card includes a remote LCP 601 connector port.
	175G0134 MCD 600 Remote Keypad/Display The VLT [®] Soft Starter MCD 600 soft starters can be used with a remote LCP mounted up to 3 m (9.8 ft) away from the soft starter. This kit contains a LCP601 + 3 meter cable and an expansion card with connection port
ľ	175G0133 MCD 600 Pumping Smart Card The MCD600 Pumping Smart Card provides dedicated inputs for pressure, depth, temperature, and flow sensors to allow protection, control, and monitoring integration in a range of pumping applications
I	175G0132 MCD 600 Profinet MCD 600 Profinet supports network communication via easy-to-install communication expansion cards. Each communication card includes a remote LCP 601 connector port.
рыя 9 5 6 а 4 ° а	175G0187 ☑ Remote Control Panel LCP601 The VLT [®] Soft Starter MCD 600 soft starters can be used with a remote LCP mounted up to 3 m (9.8 ft) away from the soft starter. This kit contains a LCP601 + 3 meter cable. Can be connected to existing communication card
Image coming soon	175G0030 년 Modbus TCP Option NIC52 version GF
Image coming soon	175G0031 🗹 Ethernet IP option NIC52 version GF
Image coming	175G0032 ^{IZ} ProfiNet option, NIC52 version GF

For more information, please use this link to visit the product page on Danfoss Product Store 🗈

ENGINEERING TOMORROW



Spare Parts

175G0136 Control Card for 230V ctr. Frame S1 Boards sent as spare parts are not loaded with firmware. After replacing the motor control board and/or user interface board,load firmware into the soft starter.
175G0153 № Fan Replacement Kit for small starters Models MCD6-0042B ~ MCD6-0129B require a fan
175G0156 2 Sparepart Bypass Contactor Kit 86-129A Each kit contains 1 internal bypass contactor. MCD600 soft starters requires 3 internal bypass contactors for a full replacement
175G0147 Replacement SCR Kit 0086B-0108B starter Each kit contains 1 SCR. MCD600 soft starters requires 3 SCRs for a full replacement
175G0141 ☑ Motor Control Kit for small T7 starter Motor Control Kit for Frame size S1, Mains Voltage T7 (380-690V). Boards sent as spare parts are not loaded with firmware. After replacing Control Card, load firmware into the soft starter.
175G0135 Kit Enclosure Opening Tools MCD 600 Opening Tools MCD 600 in case of service. Tool consist of two parts to be used at top an bottom to release locks

Services



130R1131 🛛

DrivePro ExWarr Work Shop PG04 30 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store 🗅



Services

130R1134 ☑ DrivePro ExWarr Work Shop PG04 48 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1135 ☑ DrivePro ExWarr Work Shop PG04 54 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1137 ☑ DrivePro ExWarr Work Shop PG04 66 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1138 ☑ DrivePro ExWarr Work Shop PG04 72 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1136 ☑ DrivePro ExWarr Work Shop PG04 60 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1130 DrivePro ExWarr Work Shop PG04 24 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store 🗈



Services

130R1132 DrivePro ExWarr Work Shop PG04 36 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1133 ☑ DrivePro ExWarr Work Shop PG04 42 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1034 ☑ DrivePro ExWarr Onsite PG04 48 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1031 ☑ DrivePro ExWarr Onsite PG04 30 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
 130R1032 ≥ DrivePro ExWarr Onsite PG04 36 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1035 ☑ DrivePro ExWarr Onsite PG04 54 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store 🗈

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.



Services

 130R1033 ☑ DrivePro ExWarr Onsite PG04 42 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1030 DrivePro ExWarr Onsite PG04 24 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1038 ☑ DrivePro ExWarr Onsite PG04 72 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1036 ☑ DrivePro ExWarr Onsite PG04 60 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
 130R1037 ☑ DrivePro ExWarr Onsite PG04 66 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store 🗈