



# 136G7362 🛽

## MCD60244BT7S2X00CV1

This product is not available in this store. Please contact your local <a href="{0}" class="arrow-xs active customer-care-link">Customer Service Center</a>. **Customer Service Center** [조

MCD60244BT7S2X00CV1

MCD60244BT7S2X00CV1 VLT\* Soft Starter MCD 600 With Int. Bypass Contactor 244 A, Three phase 380-690 V AC Frame size 2, IP00 Control Voltage: 24 VAC/VDC Other options according to Model code

Model code: MCD60244BT7S2X00CV1

VLT\* Soft Starter MCD 600 is a total motor starting solution.
Current transformers measure motor current and provide feedback for controlled motor ramp profiles.
Adaptive Acceleration Control (AAC) automatically employs the best starting and stopping profile for the application.
Emergency mode and Pump clean function are standard features.
The optional remote control panel adds more functionality, such as the Start/Stop buttons, and quick jump buttons to menu options.
VLT\* Soft Starter MCD 600 is available in three enclosure sizes: S1, S2 and S3
S1: IP20 with built-in bypass contactor (20–129 A)
S2: IP00 either with built-in bypass or non-bypass (144 – 579 A).
S3: IP00 with built-in bypass, non-bypass or external bypass (590–1250 A)

To achieve protection rating IP20 on connections, order the Finger Guard Kit as an accessory.

#### **PRODUCT DETAILS**

	14 kg		
	12.7 kg		
	59.4		
	5710108638474		
0001	No grouping		
RIES			
GLBL	Global (Standard)		
MCD	MCD Soft Starter series		
6	600 Series		
0244	244 A		
В	With Int. Bypass Contactor		
Т	Three phase		
7	Three phase 380-690 V AC		
S2	Frame size 2		
Х	Reserved		
	RIES GLBL MCD 6 0244 B T T 7 52		

### Product Detail | MCD60244BT7S2X00CV1



### PRODUCT DETAILS

IP Rating	00	IP00	
Control Voltage	CV1	24 VAC/VDC	
Typecode Part 1		MCD60244BT7S2X00CV1	
Product Catalog	NO_VIEW	NO VIEW	
Modelcode01		MCD60244BT7S2X00CV1	
Calculated Gross Weight [kg]		16.3	
Calculated Net Weight [kg]		15.5	
Material Gross Weight		14	
Material Net Weight		12.7	
Vendor	ERR01	Cannot Determine Vendor	
Recommended Factory	ERR01	Cannot Determine Vendor	

For Documents, Software, Visuals and more information, please use this link to visit the product page on Danfoss Product Store 🗈

MI	<b>175G0186</b> <b>MCD 600 Finger guards for 0144B-0579B</b> Finger guards provide IP20 protection when used with cable of diameter 22 mm or greater.
	<b>175G0131 </b> <b>MCD 600 Ethernet/IP</b> MCD 600 Ethernet/IP supports network communication via easy-to-install communication expansion cards. Each communication card includes a remote LCP 601 connector port.
Į.	<b>175G0127 ট</b> <b>MCD 600 Modbus RTU</b> MCD 600 Modbus RTU supports network communication via easy-to-install communication expansion cards. Each communication card includes a remote LCP 601 connector port.
Į.	175G0128 MCD 600 Profibus MCD 600 Profibus supports network communication via easy-to-install communication expansion cards. Each communication card includes a remote LCP 601 connector port.
Ð	<b>175G0129 ≥</b> MCD 600 Devicenet MCD 600 Devicenet supports network communication via easy-to-install communication expansion cards. Each communication card includes a remote LCP 601 connector port.

#### For more information, please use this link to visit the product page on Danfoss Product Store 🗅

ENGINEERING TOMORROW

	175G0130 🖻
A C	MCD 600 Modbus TCP
P	MCD 600 Modbus TCP supports network communication via easy-to-install
	communication expansion cards. Each communication card includes a remote
	LCP 601 connector port.
	175G0134 ⊵
	MCD 600 Remote Keypad/Display
****	The VLT® Soft Starter MCD 600 soft starters can be used with a remote
	LCP mounted up to 3 m (9.8 ft) away from the soft starter. This kit
	contains a LCP601 + 3 meter cable and an expansion card with connection
	port
	175G0133 🛙
1e	MCD 600 Pumping Smart Card
E	The MCD600 Pumping Smart Card provides dedicated inputs for pressure,
	depth, temperature, and flow sensors to allow protection, control, and
	monitoring integration in a range of pumping applications
	175G0132 🛙
	MCD 600 Profinet
1 Contraction of the second se	MCD 600 Profinet supports network communication via easy-to-install
	communication expansion cards. Each communication card includes a remote
	LCP 601 connector port.
24	175G0187 🖻
	Remote Control Panel LCP601
****	The VLT® Soft Starter MCD 600 soft starters can be used with a remote
	LCP mounted up to 3 m (9.8 ft) away from the soft starter. This kit
	contains a LCP601 + 3 meter cable. Can be connected to existing
	communication card
	175G0030 년
Image coming soon	Modbus TCP Option NIC52 version GF
	17560021 (2
Image	175G0031 E Ethernet IP option NIC52 version GE
coming soon	Ethernet IP option NIC52 version GF
	175G0032 🖻
Image coming	ProfiNet option, NIC52 version GF

#### For more information, please use this link to visit the product page on Danfoss Product Store 🗈

ENGINEERING TOMORROW



**Spare Parts** 

- 0					5
88	80	1	10		8
1.0	볛.	100		8	
100	18		816	331	
1953		11.00			

### 175G0138 🖻

**Control Card for 24V ctl.Frame S1,S2,S3** Control Card for 24V ctl.Frame size S1,S2 and S3. Boards sent as spare parts are not loaded with firmware. After replacing Control Card, load firmware into the soft starter.



## 175G0154 🕑

Fan Replacement Kit for large starters Models MCD6-0144B ~ MCD6-1250B require a fan



### 175G0142 🛽

**Motor Control Kit for big T7 starter** Motor Control Kit for Frame size S2,S3 Mains Voltage T7(380-690V). Boards sent as spare parts are not loaded with firmware. After replacing Control Card, load firmware into the soft starter.



### 175G0157 🖄

**Sparepart Bypass Contactor Kit 171-244A** Each kit contains 1 internal bypass contactor. MCD600 soft starters requires 3 internal bypass contactors for a full replacement



### 175G0185 🕑

**Replacement SCR Kit for 0243B Starter** Each phase arm kit contains 1 SCR. MCD600 soft starters requires 3 phase ark kits for a full replacement

### 175G0135 🛛

**Kit Enclosure Opening Tools MCD 600** Opening Tools MCD 600 in case of service. Tool consist of two parts to be used at top an bottom to release locks

Services



## 130R1131 🛛

DrivePro ExWarr Work Shop PG04 30 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

#### For more information, please use this link to visit the product page on Danfoss Product Store 🗷



#### Services

130R1134 DrivePro ExWarr Work Shop PG04 48 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
<b>130R1135</b> ☑ <b>DrivePro ExWarr Work Shop PG04 54 months</b> DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
<b>130R1137</b> ☑ <b>DrivePro ExWarr Work Shop PG04 66 months</b> DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
<b>130R1138 </b> ☑ <b>DrivePro ExWarr Work Shop PG04 72 months</b> DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1136 DrivePro ExWarr Work Shop PG04 60 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1130 ₪ DrivePro ExWarr Work Shop PG04 24 months DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

### For more information, please use this link to visit the product page on Danfoss Product Store 🗈

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.



#### Services

<ul> <li>130R1132 ☑</li> <li>DrivePro ExWarr Work Shop PG04 36 months</li> <li>DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.</li> <li>You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.</li> </ul>
<b>130R1133</b> ☑ <b>DrivePro ExWarr Work Shop PG04 42 months</b> DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
<b>130R1034</b> ☑ <b>DrivePro ExWarr Onsite PG04 48 months</b> DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
<b>130R1031</b> ☑ <b>DrivePro ExWarr Onsite PG04 30 months</b> DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
<ul> <li>130R1032 ▷</li> <li>DrivePro ExWarr Onsite PG04 36 months</li> <li>DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.</li> <li>You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.</li> </ul>
<b>130R1035</b> ☑ <b>DrivePro ExWarr Onsite PG04 54 months</b> DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

### For more information, please use this link to visit the product page on Danfoss Product Store 🗈



#### Services

<ul> <li>130R1033 ☑</li> <li>DrivePro ExWarr Onsite PG04 42 months</li> <li>DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.</li> <li>You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.</li> </ul>
130R1030 ☑ DrivePro ExWarr Onsite PG04 24 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
130R1038 ☑ DrivePro ExWarr Onsite PG04 72 months DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.
<b>130R1036</b> ☑ <b>DrivePro ExWarr Onsite PG04 60 months</b> DrivePro® On-site Extended Warranty provides repair at the customer         site, or replacement at the customer site.         You can only order DrivePro® Extended Warranty when purchased with a new         drive. For drives previously shipped or purchased; contact your local         Danfoss Drives sales office for extended warranty contract options.
<ul> <li>130R1037 ☑</li> <li>DrivePro ExWarr Onsite PG04 66 months</li> <li>DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.</li> <li>You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.</li> </ul>

### For more information, please use this link to visit the product page on Danfoss Product Store 🗈