



135N2498

70-AB3L00315W05B521BM26-00059182

Frequency converter
 VACON0100-3L-0031-5+IP54+DPAP+FBIE
 VACON 100 Industrial
 380-500 Vac, 31 Amp, IP54/NEMA12
 Graphical Keypad MK01
 C2 Commercial&Industry Environ
 B Slot: F3,3 Relay board
 C Slot: No board
 D Slot: No board
 E Slot: No board
 Fieldbus: IndEth (ProfinetIO, EthernetIP)
 Manual: English
 Frame 05
 Other options according to Model code

Model code: VACON0100-3L-0031-5+IP54+DPAP+FBIE

VACON® 100 AC drives are ideal for saving energy, optimizing process control and improving productivity. They are designed for multi-purpose use while remaining easy to install, easy to commission and easy to operate. The variants VACON® INDUSTRIAL and VACON® FLOW are available in power range 0.55-800 kW, voltage range 208-690 V, and protection ratings IP00, IP21/UL Type 1 and IP54/UL Type 12.

PRODUCT DETAILS

Gross weight		11 kg
Net weight		10 kg
Volume		0 l
EAN		5710108186661
VACON 0100		
Product View (Switch)	GLBL	Global (Standard)
Segment	NONE	VACON 100 Industrial
Region Code	-R00	R00 International
Mains voltage	-5	380-500 Vac
Current rating	-0031	31 Amp
Installation options	-DM	DM Drive Module
Enclosure	+IP54	IP54/NEMA12
Control panel	+HMGR	Graphical Keypad MK01
EMC emission limit category	+EMC2	C2 Commercial&Industry Environ
Common mode filter (for DM)	+P000	No Option
DUT filter (for DM)	+P000	No Option
Brake chopper	+DBIN	Integrated Brake Chopper
Real time clock option	+SRNO	No Battery for real time clock
Configurable power range	NONE	None
Power connections	+P000	No Power options (+P000)
Cable entry	+QGLM	Metric conduit plate
Additional Equipment B	+Q000	No option for Qxxx_B (+Q000)
Additional Equipment C	+Q000	No additional option for Qxxx_C
Shipping package	+GSCB	Cardboard Box as Shipping pack

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

PRODUCT DETAILS

Marine construction	+E000	no option
B-Slot Option Board	+SBF3	F3,3 Relay board
C- Slot Option Board	+SC00	No board
D-Slot Option Board	+SD00	No board
E-Slot Option Board	+SE00	No board
Internal FB selection	+FBIE	IndEth (ProfinetIO,EthernetIP)
Documentation level	+DPAP	Paper Manuals
Document language preference	+DLUK	English
Firmware Language Pack	+FL01	UK, DE, FI, SE, IT, FR lang
Application	+A0000	No Application
Parameter Set	+L0000	No application parameter set
Motor parameter default freq	+LS50	50 Hz def motor freq settings
Unit for measure for display	+LSSI	Metric Units of Measure
Labeling options	+LPC1	no additional labels
UL approval	+GAUL	UL Approval (+GAUL)
Marine approval	NONE	None
RCM Approval	+GACT	(+GACT) RCM Approval N16307
KC approval	+GAKC	KC Approval
Ukrainian approval	+GAUA	Ukrainian Approval
EAC Approval	+GAEA	EAC Approval
Auxiliary power supply	+C000	no option (+C000)
DC power supply for aux device	+C000	no option (+C000)
AC socket for aux devices	+C000	no option (+C000)
Input Devices	NONE	none_
Common mode filter (for ED)	+P000	no option
DU/DT, Sine filter (for ED)	+P000	no option
Terminal Options	NONE	none_
Door Equipments	+C000	no option (+C000)
Cabinet heater	+C000	no option (+C000)
Cabinet light	+C000	no option (+C000)
Motor heater control	+C000	no option (+C000)
Emergency stop options	+C000	no option (+C000)
Insulation fault sensor	+C000	no option (+C000)
Cabling from top	+C000	no option (+C000)
Back channel cooling	+C000	no option (+C000)
Cabinet Plinth	+C000	no option (+C000)
Empty extension segment	NONE	None
Standardized cabinet solution	NONE	None
Engineered cabinet solution	NONE	None
Product Group	VACON	VACON
Product Series	0100	Vacon 100 series
Phase	-3L	3 Phase AC Input
Customized	+BM26	Vacon 100
Main Circuit	+M000	NONE
Firmware	+F0072	Vacon0100 Software package
Max output frequency	NONE	None
Terminal Box	+T000	NONE
Bypass Control Operation Mode	NONE	none_
Bypass Input Type	NONE	none_
Bypass power connection type	NONE	none_
CE approval	+GACE	CE Approval (+GACE)

Product Detail | 70-AB3L00315W05B521BM26-00059182

PRODUCT DETAILS

ATEX Approval	NONE	None
County Specific Approval	NONE	None
Warrenty time	+WT01	Warranty 12/18 months (+WT01)
Frame Size	MR05	Frame 05
Product Catalog	NO_VIEW	NO VIEW
Modelcode01		VACON0100-3L-0031-5
Modelcode02		+IP54+DPAP+FBIE
Calculated Net Weight [kg]		10
Calculated Gross Weight [kg]		11
Motor Power Low Overload [kW]		15
Motor Power High Overload [kW]		11
Dimensions WxHxD [mm] net		144 X 419 X 214
Dimensions WxHxD [mm] Gross		190 X 477 X 257
Dimensions WxHxD [mm]		144X419X214
Continuous Current (NO) [A]		31
Continuous Current (HO) [A]		23
Motor Power HP Low Overload		20
Motor Power HP High Overload		15
Typecode Part 1		70-AB3L00315W05B521BM26
Typecode Part 2		-00059182
Stockcode part 1		70-AB3L00315W05B521BM26
Stockcode part 2		-00059182
check if complete		OK
Vendor	ERR01	Cannot Determine Vendor
Recommended Factory	ERR01	Cannot Determine Vendor
Help Counter		15
Help Counter		2
Calculated Net Weight		10
Material Gross Weight		11
Material Net Weight		10
Salestext		MR05-0031-5+IP54+EMC2
Sub family identification	NONE	Normal customer ordered
ECCN US		3A999.a
ECCN EU		X.A.I.003

For Documents, Software, Visuals and more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Accessories



181B0586 [🔗](#)

OPT-E7-V:DeviceNet

OPT-E7-V

Image
coming
soon

181B0761 [🔗](#)

OPT-EC-V:EtherCAT

OPT-EC-V

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**181B3287** [🔗](#)**OPT-EA-V:Advanced 2-port ethernet**

OPT-EA-V

**181B1472** [🔗](#)**OPT-B2-V+DLES:1RO(NO/NC),1RO(NO),therm**

OPT-B2-V+DLES

**181B1473** [🔗](#)**OPT-B4-V+DLES:AI,2AO(mA,isol),+24V/EXT**

OPT-B4-V+DLES

**181B1481** [🔗](#)**OPT-B1-V+DNOT:6 programmableDI/DO**

OPT-B1-V+DNOT

**181B1738** [🔗](#)**OPT-B4-V+DLFR:AI,2AO(mA,isol),+24V/EXT**

OPT-B4-V+DLFR

**181B2134** [🔗](#)**OPT-B2-V+DLDE:1RO(NO/NC),1RO(NO),therm**

OPT-B2-V+DLDE

**181B2151** [🔗](#)**OPT-B2-V+DNOT:1RO(NO/NC),1RO(NO),therm**

OPT-B2-V+DNOT

**181B2152** [🔗](#)**OPT-B4-V+DNOT:AI,2AO(mA,isol),+24V/EXT**

OPT-B4-V+DNOT

**181B0302** [🔗](#)**OPT-B2-V:1RO(NO/NC),1RO(NO),therm**

OPT-B2-V

**181B0301** [🔗](#)**OPT-B1-V:6 programmableDI/DO**

OPT-B1-V

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



181B0303 [🔗](#)
OPT-B4-V:AI,2AO(mA,isol),+24V/EXT
OPT-B4-V



181B0304 [🔗](#)
OPT-B5-V:3RO(NO)
OPT-B5-V



181B0307 [🔗](#)
OPT-B9-V:1RO(NO),5pcs of 41-240VAC
OPT-B9-V



181B0623 [🔗](#)
OPT-B5-V+DNOT:3RO(NO)
OPT-B5-V+DNOT



181B0794 [🔗](#)
OPT-B1-V+DLES:6 programmableDI/DO
OPT-B1-V+DLES



181B0795 [🔗](#)
OPT-B1-V+DLDE:6 programmableDI/DO
OPT-B1-V+DLDE



181B0796 [🔗](#)
OPT-B4-V+DLDE:AI,2AO(mA,isol),+24V/EXT
OPT-B4-V+DLDE



181B0797 [🔗](#)
OPT-B5-V+DLES:3RO(NO)
OPT-B5-V+DLES



181B0798 [🔗](#)
OPT-B5-V+DLDE:3RO(NO)
OPT-B5-V+DLDE



181B0311 [🔗](#)
OPT-BH-V:3 temp meas channels
OPT-BH-V

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**181B0310** [🔗](#)**OPT-BF-V:**
OPT-BF-V**181B0450** [🔗](#)**OPT-BJ-V:**
OPT-BJ-VImage
coming
soon**181B4132** [🔗](#)**OPT-E2-V:RS485 (Modbus/N2)**
OPT-E2-V**181B1485** [🔗](#)**OPT-C4-V+DNOT:LonWorks**
OPT-C4-V+DNOTImage
coming
soon**141F4277** [🔗](#)**AS-interface Fieldbus Option, OPT-BK-V**
OPT-BK-V**181B1482** [🔗](#)**OPT-BJ-V+DLES:**
OPT-BJ-V+DLES**181B2155** [🔗](#)**OPT-BJ-V+DLFI:**
OPT-BJ-V+DLFI**181B0800** [🔗](#)**OPT-BJ-V+DLDE:**
OPT-BJ-V+DLDE**181B0316** [🔗](#)**OPT-C4-V:LonWorks**
OPT-C4-VImage
coming
soon**181B3273** [🔗](#)**OPT-F5-V:**
OPT-F5-V**For more information, please use this link to visit the product page on Danfoss Product Store** [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

Image
coming
soon**181B4135** [🔗](#)**OPT-E8-V:RS485 with Sub-D9**

OPT-E8-V

Image
coming
soon**181B2164** [🔗](#)**OPT-E9-V+DNOT:2-port ethernet**

OPT-E9-V+DNOT

**181B1488** [🔗](#)**OPT-E5-V+DNOT:PROFIBUS DP with Sub-D9**

OPT-E5-V+DNOT

**181B1487** [🔗](#)**OPT-E3-V+DNOT:PROFIBUS DP**

OPT-E3-V+DNOT

**181B0492** [🔗](#)**OPT-E9-V:2-port ethernet**

OPT-E9-V

**181B0330** [🔗](#)**OPT-F4-V:**

OPT-F4-V

**181B0329** [🔗](#)**OPT-F3-V:**

OPT-F3-V

**181B0327** [🔗](#)**OPT-E6-V:CANopen**

OPT-E6-V

**181B0326** [🔗](#)**OPT-E5-V:PROFIBUS DP with Sub-D9**

OPT-E5-V

**181B0075** [🔗](#)**MR5 IP54 -kit**

VACON-ENC-IP54-MR05

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

Image coming soon

141F4210 [🔗](#)
VACON-DEM-0100-1L-2-CASE democase
 VACON-DEM-0100-1L-2-CASE

Image coming soon

181B5386 [🔗](#)
OPT-B9-V+DNOT:1RO(NO),5pcs of 41-240VAC
 OPT-B9-V+DNOT

Spare Parts



181B1401 [🔗](#)
Discharging resistor assembly 48k 1 mm
 SPR-ELE15323



181B1100 [🔗](#)
Terminal connector kit Vacon100
 SPR-ELE02023



181B1092 [🔗](#)
Control flat cable MR05
 SPR-ELE01783



181B1158 [🔗](#)
EMC jumper 10pcs
 SPR-ELE08056



181B1157 [🔗](#)
MR Ground Fault Transformer Current Sens
 SPR-ELE08037



181B1049 [🔗](#)
Internal fan
 SPR-MEC00978



181B1174 [🔗](#)
"MR05 Accessories kit, inch"
 SPR-MEC02004

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



181B1206 [🔗](#)
MR05 Gland plate kit IP54, inch
SPR-MEC08050



181B1203 [🔗](#)
"MR05 Gland plate kit IP54, metric"
SPR-MEC08047



181B1200 [🔗](#)
"MR05 Gland plate kit IP21, inch"
SPR-MEC08043



181B1197 [🔗](#)
"MR05 Gland plate kit IP21, metric"
SPR-MEC08039



181B2990 [🔗](#)
Skiip 34NAB176V1 1700V 60A
SPR-ELE14770



181B2354 [🔗](#)
Fuse switch OS63030P
SPR-ELE13938



181B0641 [🔗](#)
Control board MC04
SPR-CMB06634



181B0916 [🔗](#)
Diode thyristor module SKKH 162/18E
SPR-ELE14690



181B0809 [🔗](#)
"MR05 Accessories kit, metric"
SPR-MEC01798



181B0764 [🔗](#)
Main fan MR08 48VDC
SPR-MEC01861

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

**181B0384** [🔗](#)**Main fan MR05**

SPR-MEC00977

**181B0378** [🔗](#)**Control unit V100 (MC04 w/o I/O board)**

SPR-CMB06633

**181B2996** [🔗](#)**DC-capacitor 350uF 800V MR05**

SPR-ELE27403

**181B1116** [🔗](#)**MR05 Main Cover IP54 Dark Grey, NCS 7010**

VACON-SPR-MEC01962

**181B1117** [🔗](#)**Main Cover MR05 IP21 Dark Grey, NCS 7010**

VACON-SPR-MEC01963

**181B1121** [🔗](#)**MR05 HVAC/FLOW/100 Main cover assembly**

VACON-SPR-MEC01978-HVAC

**181B1387** [🔗](#)**MR05 Main Cover Dark Grey IP54**

VACON-SPR-MEC01962-HVAC

**181B1393** [🔗](#)**MR05 Main Cover IP21 Dark Grey, NCS 7010-R90B**

VACON-SPR-MEC01963-HVAC

**181B2997** [🔗](#)**I/O GND plate + connector cover kit MR05**

SPR-MEC08053

**181B3729** [🔗](#)**Measurement board Vacon 200/500/600/690V**

SPR-CMB15267+AMPV0062-6+MODX2V001+DBNO-R02+LS60+LSUS

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

Image
coming
soon**181B4121** **Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV0920-5+MODX2V001+DBIN-R00+LS50+LSSI

**181B4122** **Power Board 34A 690V MR6**

SPR-CMB14772-FLOW+AMPV0027-6+MODX1V001+DBIN-R02+LS60+LSUS

Image
coming
soon**181B4123** **Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV0920-5+MODX2V001+DBNO-R00+LS50+LSSI

**181B4098** **Measurement board 500/690V MR10**

SPR-CMB21899+AMPV0590-5+MODX2V001+DBNO-R00+LS60+LSSI

Image
coming
soon**181B4101** **Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV1180-5+MODX2V001+DBNO-R00+LS60+LSSI

Image
coming
soon**181B4103** **Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV1180-5+MODX2V001+DBIN-R00+LS50+LSSI

**181B4307** **Power Board 34A 690V MR6**

SPR-CMB14772-HVAC+AMPV0018-6+MODX1V001+DBIN-R00+LS50+LSSI

**181B3429** **Power Board 38-61A 500V for MR06 Gen2**

SPR-CMB04711-FLOW+AMPV0046-5+MODX1V001+DBNO-R00+LS50+LSSI

**181B4729** **Measurement board MR09B MR10, programmed**

SPR-CMB21899+AMPV0520-5+MODX2V001+DBNO-R00+LS50+LSSI

**181B4770** **Measurement board Vacon 200/500/600/690V**

SPR-CMB15267-FLOW+AMPV0144-7+MODX1V001+DBNO-R00+LS50+LSSI

For more information, please use this link to visit the product page on Danfoss Product Store 

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



181B4866 [🔗](#)
Measurement board V100, pre-programmed
 SPR-CMB29585+AMPVXXX-7-X1-B



181B4865 [🔗](#)
Measurement board V100, pre-programmed
 SPR-CMB29585+AMPVXXX-5-X2-B



181B4864 [🔗](#)
Measurement board V100, pre-programmed
 SPR-CMB29585+AMPVXXX-5-X1-B



181B4893 [🔗](#)
Measurement board Vacon 200/500/600/690V
 SPR-CMB15267-FLOW+AMPV0041-6+MODX2V001+DBIN-R00+LS50+LSSI

Image coming soon

181B5064 [🔗](#)
Control cover semi-matt for MR09
 VACON-SPR-MEC02014

Image coming soon

181B5303 [🔗](#)
Measurement boards MR11 MR12, programmed
 SPR-CMB33055+AMPV0730-5+MODX1V001+DBNO-R00+LS50+LSSI

Image coming soon

181B5417 [🔗](#)
Miniature circuit breaker 2A 1P NAM
 SPR-ELE25089

Image coming soon

181B5418 [🔗](#)
Miniature circuit breaker 6A 1P NAM
 SPR-ELE25087

Image coming soon

181B5425 [🔗](#)
Modular socket 15A 125VAC 1P NAM
 SPR-ELE25093

Image coming soon

181B5428 [🔗](#)
Measurement board 240/500V MR7-9, prog
 SPR-CMB01790-HVAC+AMPV0261-5+MODX1V001+DBNO-R00+LS50+LSSI

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

**181B5438** [🔗](#)**Accessories bag with ext. box, 2-cabling**

SPR-MEC41716

Image
coming
soon**181B5445** [🔗](#)**Measurement board 240/500V MR7-9, prog**

SPR-CMB01790+AMPV0205-5+MODX1V001+DBNO-R00+LS50+LSSI

**181B5470** [🔗](#)**Cable gland plate IP54 for MR07, metric**

SPR-MEC44149

Image
coming
soon**181B5489** [🔗](#)**Plate heat exchanger, type:M3-FG-70PL**

SPR-SOL44167

Image
coming
soon**181B5490** [🔗](#)**Regulating valve actuator + 24VDC-module**

SPR-SOL44168



x6

181B5756 [🔗](#)**Filter mat 270x270mm (incl. 6 pcs)**

SPR-MEC43925



x6

181B5755 [🔗](#)**Filter mat 85x85mm (incl. 6 pcs)**

SPR-MEC43915

Image
coming
soon**181B5775** [🔗](#)**Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV1040-5+MODX2V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5786** [🔗](#)**Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV0820-7+MODX1V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5788** [🔗](#)**Regulating 3-way valve DN32**

SPR-SOL44682

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

Image
coming
soon**181B5792** [🔗](#)**Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV0650-5+MODX1V001+DBNO-R00+LS50+LSSI

**181B5815** [🔗](#)**Main fan assembly MR9**

SPR-ELE44150

**181B5816** [🔗](#)**Main fan with power assembly MR9**

SPR-ELE44935

**181B5828** [🔗](#)**Charging Switch INU-FI9-FI10-V2**

65-ELE43838-1194X2

**181B5831** [🔗](#)**IGBT and driver board assy 690V MR09b**

65-ELE38906-117UHW

**181B5830** [🔗](#)**Brake IGBT and driver assy 690V MR09b**

65-ELE38905-117UHV

**181B5845** [🔗](#)**Measurement board Vacon 200/500/600/690V**

SPR-CMB15267+AMPV0144-7+MODX1V001+DBNO-R00+LS50+LSSI

**181B0275** [🔗](#)**DC-power supply**

STL-EST09693

**181B0861** [🔗](#)**Software service kit for Vacon100**

STL-EST10606

Image
coming
soon**181B5864** [🔗](#)**Powerboard 16-31A 500V for MR5 Gen3**

SPR-CMB33714-FLOW+AMPV0031-5+MODX2V001+DBNO-R00+LS50+LSSI

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

Image
coming
soon**181B5865** [🔗](#)**Powerboard 16-31A 500V for MR5 Gen3**

SPR-CMB33714+AMPV0031-5+MODX2V001+DBIN-R00+LS50+LSSI

Image
coming
soon**181B5872** [🔗](#)**Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV0820-5+MODX2V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5880** [🔗](#)**Measurement board MR09B MR10, programmed**

SPR-CMB21899+AMPV0416-7+MODX1V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5897** [🔗](#)**Measurement board 240/500V MR7-9, prog**

SPR-CMB01790-FLOW+AMPV0072-5+MODX1V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5902** [🔗](#)**Measurement board Vacon 200/500/600/690V**

SPR-CMB15267-FLOW+AMPV0052-7+MODX2V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5903** [🔗](#)**Measurement board 240/500V MR7-9, prog**

SPR-CMB01790+AMPV0170-2+MODX1V001+DBNO-R00+LS60+LSSI

Image
coming
soon**181B5908** [🔗](#)**Shipping box inc. dampers size 4 (4 pcs)**

SPR-MEC46233

Image
coming
soon**181B5909** [🔗](#)**Shipping box inc. dampers size 5 (4 pcs)**

SPR-MEC46234

Image
coming
soon**181B5910** [🔗](#)**Shipping box inc. dampers size 6 (4 pcs)**

SPR-MEC46235

Image
coming
soon**181B5911** [🔗](#)**Shipping box inc. dampers size 7 (4 pcs)**

SPR-MEC46236

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

Image
coming
soon**181B5912** [🔗](#)**Shipping box inc. dampers size 8 (4 pcs)**

SPR-MEC46237

Image
coming
soon**181B5948** [🔗](#)**Measurement board 105-310A 240/500V MR7-**

SPR-CMB01790+AMPV0105-5+MODX2V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5950** [🔗](#)**Thermal paste Wacker P12, 90ML**

STL-MST46417

Image
coming
soon**181B5951** [🔗](#)**Thermal paste Dowsil TC-6000HP, 1kg**

STL-MST46857

Image
coming
soon**181B6056** [🔗](#)**Fuse 800A 690VAC aR Size 2**

SPR-ELE45855

Image
coming
soon**181B6057** [🔗](#)**Fuse 1000A 690VAC aR Size 3**

SPR-ELE45856

Image
coming
soon**181B6058** [🔗](#)**Fuse 1100A 690VAC aR Size 3**

SPR-ELE45857

Image
coming
soon**181B6059** [🔗](#)**Fuse 1250A 690VAC aR Size 3**

SPR-ELE45858

Image
coming
soon**181B6053** [🔗](#)**Fuse 250A 690VAC aR Size 1**

SPR-ELE45828

Image
coming
soon**181B6054** [🔗](#)**Fuse 400A 690VAC aR Size 1**

SPR-ELE45829

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

Image
coming
soon**181B6055** [🔗](#)**Fuse 630A 690VAC aR Size 2**

SPR-ELE45854

Image
coming
soon**181B6064** [🔗](#)**DC cable kit 500V for MR7**

SPR-ELE47175

**181B6158** [🔗](#)**Power Board 34A 690V MR6**

SPR-CMB14772+AMPV0034-7+MODX1V001+DBIN-R00+LS50+LSSI

**181B6160** [🔗](#)**Powerboard 500V MR5 Gen3, pre-prog, TEST**

SPR-CMB47781+AMPVXXXX-5+MODX1V001+DBIN-R00+LS50+LSSI

Services

**130R1120** [🔗](#)**DrivePro ExWarr Work Shop PG03 24 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1122** [🔗](#)**DrivePro ExWarr Work Shop PG03 36 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1123** [🔗](#)**DrivePro ExWarr Work Shop PG03 42 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1126** [🔗](#)**DrivePro ExWarr Work Shop PG03 60 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1125** [🔗](#)**DrivePro ExWarr Work Shop PG03 54 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1124** [🔗](#)**DrivePro ExWarr Work Shop PG03 48 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1127** [🔗](#)**DrivePro ExWarr Work Shop PG03 66 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1128** [🔗](#)**DrivePro ExWarr Work Shop PG03 72 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1024** [🔗](#)**DrivePro ExWarr Onsite PG03 48 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1025** [🔗](#)**DrivePro ExWarr Onsite PG03 54 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1020** [🔗](#)**DrivePro ExWarr Onsite PG03 24 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1022** [🔗](#)**DrivePro ExWarr Onsite PG03 36 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1021** [🔗](#)**DrivePro ExWarr Onsite PG03 30 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1027** [🔗](#)**DrivePro ExWarr Onsite PG03 66 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1026** [🔗](#)**DrivePro ExWarr Onsite PG03 60 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1028** [🔗](#)**DrivePro ExWarr Onsite PG03 72 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1023** [🔗](#)**DrivePro ExWarr Onsite PG03 42 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1303** [🔗](#)**DrivePro Start-Up unit pre-order small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1313** [🔗](#)**DrivePro Start-Up 1 day on-demand small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

**130R1312** [🔗](#)**DrivePro Start-Up 1 Day Pre-order small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1304** [🔗](#)**DrivePro Start-Up unit on-demand small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

Image
coming
soon

130R1380 [🔗](#)**DrivePro Start-Up ½ day pre-order small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

General Terms and Conditions of Delivery and Warranty apply.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

Image
coming
soon**130R1381** **DrivePro Start-up ½ day on-demand small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

General Terms and Conditions of Delivery and Warranty apply.

For more information, please use this link to visit the product page on Danfoss Product Store 

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.