

# Wedge Clamp

The Wedge clamp is used with the Pull Trip Type Pull Wire

Switch as well as the Chute Block Detector Tilt Switch.




## TECHNICAL SPECS & ORDERING DATA


Product Type	Part No.	Diameters
Wedge Clamp	SSCE-WC-7-13	7 - 13 mm
	SSCE-WC-9-19	9 - 19 mm

**FOR UNIVERSAL USE**

## DIMENSIONS




SIDE VIEW




TOP SIDE

## RECOMMENDED INSTALLATION



**PULL WIRE SWITCH  
ESSENTIALS SUMMARY**

**PRODUCT SPECIFIC\***




**Slack Wire Spring Tensioning Kit**

**UNIVERSAL\***




**Steel Wire Rope**  
Pull Wire

**PRODUCT SPECIFIC\***



**Black Line Cable**  
Monitoring Control Cable

**UNIVERSAL\***



**Pigtail Quick Clip**  
Cable & Pull Wire support

**UNIVERSAL\***



**Pigtails 1 Turn**  
Cable & Pull Wire support

**UNIVERSAL\***



**Pigtail 1.5 Turn**  
Cable & Pull Wire support

**UNIVERSAL\***



**Emergency Stop Label**  
On Pull Wire Rope and Monitoring Cable

**PRODUCT SPECIFIC\***



**Canopy**  
Additional mechanical protection for Pull Trip Type Pull Wire Switch

**UNIVERSAL\***



**Wedge Clamp**  
Cable support for Pull Trip Type Pull Wire Switch

\* Universal: The essential product is universal to other systems including Safe-T-Pull and NHP systems.  
 ^ Product Specific: To be used with Smart Series product range only.