



135N2603

70-AB3L00615W06B520BM2H-00049062

Frequency converter
 VACON0100-3L-0061-5-FLOW+IP54+DPAP+FBIE
 VACON 100 FLOW
 380-500 Vac, 61 Amp, IP54/NEMA12
 Graphical Keypad MK01
 C2 Commercial&Industry Environ
 B Slot: F3,3 Relay board
 C Slot: No board
 D Slot: No board
 E Slot: No board
 Fieldbus: IndEth (ProfinetIO, EthernetIP)
 Manual: English
 Frame 06
 Other options according to Model code

Model code: VACON0100-3L-0061-5-FLOW+IP54+DPAP+FBIE

VACON® 100 AC drives are ideal for saving energy, optimizing process control and improving productivity. They are designed for multi-purpose use while remaining easy to install, easy to commission and easy to operate. The variants VACON® INDUSTRIAL and VACON® FLOW are available in power range 0.55-800 kW, voltage range 208-690 V, and protection ratings IP00, IP21/UL Type 1 and IP54/UL Type 12.

PRODUCT DETAILS

| | | |
|------------------------------------|-------|---------------------------------|
| Gross weight | | 21 kg |
| Net weight | | 20 kg |
| Volume | | 0 l |
| EAN | | 5710108187835 |
| VACON 0100 | | |
| Product View (Switch) | GLBL | Global (Standard) |
| Segment | -FLOW | VACON 100 FLOW |
| Region Code | -R00 | R00 International |
| Mains voltage | -5 | 380-500 Vac |
| Current rating | -0061 | 61 Amp |
| Installation options | -DM | DM Drive Module |
| Enclosure | +IP54 | IP54/NEMA12 |
| Control panel | +HMGR | Graphical Keypad MK01 |
| EMC emission limit category | +EMC2 | C2 Commercial&Industry Environ |
| Common mode filter (for DM) | +P000 | No Option |
| DUT filter (for DM) | +P000 | No Option |
| Brake chopper | +DBNO | No dynamic braking device |
| Real time clock option | +SRNO | No Battery for real time clock |
| Configurable power range | NONE | None |
| Power connections | +P000 | No Power options (+P000) |
| Cable entry | +QGLM | Metric conduit plate |
| Additional Equipment B | +Q000 | No option for Qxxx_B (+Q000) |
| Additional Equipment C | +Q000 | No additional option for Qxxx_C |
| Shipping package | +GSCB | Cardboard Box as Shipping pack |

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

PRODUCT DETAILS

| | | |
|---------------------------------------|--------|--------------------------------|
| Marine construction | +E000 | no option |
| B-Slot Option Board | +SBF3 | F3,3 Relay board |
| C- Slot Option Board | +SC00 | No board |
| D-Slot Option Board | +SD00 | No board |
| E-Slot Option Board | +SE00 | No board |
| Internal FB selection | +FBIE | IndEth (ProfinetIO,EthernetIP) |
| Documentation level | +DPAP | Paper Manuals |
| Document language preference | +DLUK | English |
| Firmware Language Pack | +FL01 | UK, DE, FI, SE, IT, FR lang |
| Application | +A0000 | No Application |
| Parameter Set | +L0000 | No application parameter set |
| Motor parameter default freq | +LS50 | 50 Hz def motor freq settings |
| Unit for measure for display | +LSSI | Metric Units of Measure |
| Labeling options | +LPC1 | no additional labels |
| UL approval | +GAUL | UL Approval (+GAUL) |
| Marine approval | NONE | None |
| RCM Approval | +GACT | (+GACT) RCM Approval N16307 |
| KC approval | +GAKC | KC Approval |
| Ukrainian approval | +GAUA | Ukrainian Approval |
| EAC Approval | +GAEA | EAC Approval |
| Auxiliary power supply | +C000 | no option (+C000) |
| DC power supply for aux device | +C000 | no option (+C000) |
| AC socket for aux devices | +C000 | no option (+C000) |
| Input Devices | NONE | none_ |
| Common mode filter (for ED) | +P000 | no option |
| DU/DT, Sine filter (for ED) | +P000 | no option |
| Terminal Options | NONE | none_ |
| Door Equipments | +C000 | no option (+C000) |
| Cabinet heater | +C000 | no option (+C000) |
| Cabinet light | +C000 | no option (+C000) |
| Motor heater control | +C000 | no option (+C000) |
| Emergency stop options | +C000 | no option (+C000) |
| Insulation fault sensor | +C000 | no option (+C000) |
| Cabling from top | +C000 | no option (+C000) |
| Back channel cooling | +C000 | no option (+C000) |
| Cabinet Plinth | +C000 | no option (+C000) |
| Empty extension segment | NONE | None |
| Standardized cabinet solution | NONE | None |
| Engineered cabinet solution | NONE | None |
| Product Group | VACON | VACON |
| Product Series | 0100 | Vacon 100 series |
| Phase | -3L | 3 Phase AC Input |
| Customized | +BM2H | Vacon 100-FLOW |
| Main Circuit | +M000 | NONE |
| Firmware | +F0159 | Vacon0100-Flow Software pack |
| Max output frequency | NONE | None |
| Terminal Box | +T000 | NONE |
| Bypass Control Operation Mode | NONE | none_ |
| Bypass Input Type | NONE | none_ |
| Bypass power connection type | NONE | none_ |
| CE approval | +GACE | CE Approval (+GACE) |

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Product Detail | 70-AB3L00615W06B520BM2H-00049062

PRODUCT DETAILS

| | | |
|---------------------------------------|---------|-------------------------------|
| ATEX Approval | NONE | None |
| County Specific Approval | NONE | None |
| Warrenty time | +WT01 | Warranty 12/18 months (+WT01) |
| Frame Size | MR06 | Frame 06 |
| Product Catalog | NO_VIEW | NO VIEW |
| Modelcode01 | | VACON0100-3L-0061-5 |
| Modelcode02 | | -FLOW+IP54+DPAP+FBIE |
| Calculated Net Weight [kg] | | 20 |
| Calculated Gross Weight [kg] | | 21 |
| Motor Power Low Overload [kW] | | 30 |
| Motor Power High Overload [kW] | | NV |
| Dimensions WxHxD [mm] net | | 195 X 557 X 229 |
| Dimensions WxHxD [mm] Gross | | 251 X 630 X 287 |
| Dimensions WxHxD [mm] | | 195X557X229 |
| Continuous Current (NO) [A] | | 61 |
| Continuous Current (HO) [A] | | NV |
| Motor Power HP Low Overload | | 40 |
| Motor Power HP High Overload | | NV |
| Typecode Part 1 | | 70-AB3L00615W06B520BM2H |
| Typecode Part 2 | | -00049062 |
| Stockcode part 1 | | 70-AB3L00615W06B520BM2H |
| Stockcode part 2 | | -00049062 |
| check if complete | | OK |
| Vendor | ERR01 | Cannot Determine Vendor |
| Recommended Factory | ERR01 | Cannot Determine Vendor |
| Help Counter | | 20 |
| Help Counter | | 2 |
| Calculated Net Weight | | 20 |
| Material Gross Weight | | 21 |
| Material Net Weight | | 20 |
| Salestext | | MR06-0061-5+IP54+EMC2 |
| Sub family identification | NONE | Normal customer ordered |
| ECCN US | | 3A999.A |
| ECCN EU | | X.A.I.003 |

For Documents, Software, Visuals and more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Accessories



181B0586 [🔗](#)
OPT-E7-V:DeviceNet
 OPT-E7-V

Image
coming
soon

181B0761 [🔗](#)
OPT-EC-V:EtherCAT
 OPT-EC-V

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



181B3287 [🔗](#)
OPT-EA-V:Advanced 2-port ethernet
 OPT-EA-V



181B1472 [🔗](#)
OPT-B2-V+DLES:1RO(NO/NC),1RO(NO),therm
 OPT-B2-V+DLES



181B1473 [🔗](#)
OPT-B4-V+DLES:AI,2AO(mA,isol),+24V/EXT
 OPT-B4-V+DLES



181B1481 [🔗](#)
OPT-B1-V+DNOT:6 programmableDI/DO
 OPT-B1-V+DNOT



181B1738 [🔗](#)
OPT-B4-V+DLFR:AI,2AO(mA,isol),+24V/EXT
 OPT-B4-V+DLFR



181B2134 [🔗](#)
OPT-B2-V+DLDE:1RO(NO/NC),1RO(NO),therm
 OPT-B2-V+DLDE



181B2151 [🔗](#)
OPT-B2-V+DNOT:1RO(NO/NC),1RO(NO),therm
 OPT-B2-V+DNOT



181B2152 [🔗](#)
OPT-B4-V+DNOT:AI,2AO(mA,isol),+24V/EXT
 OPT-B4-V+DNOT



181B0302 [🔗](#)
OPT-B2-V:1RO(NO/NC),1RO(NO),therm
 OPT-B2-V



181B0301 [🔗](#)
OPT-B1-V:6 programmableDI/DO
 OPT-B1-V

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



181B0303 [🔗](#)
OPT-B4-V:AI,2AO(mA,isol),+24V/EXT
 OPT-B4-V



181B0304 [🔗](#)
OPT-B5-V:3RO(NO)
 OPT-B5-V



181B0307 [🔗](#)
OPT-B9-V:1RO(NO),5pcs of 41-240VAC
 OPT-B9-V



181B0623 [🔗](#)
OPT-B5-V+DNOT:3RO(NO)
 OPT-B5-V+DNOT



181B0794 [🔗](#)
OPT-B1-V+DLES:6 programmableDI/DO
 OPT-B1-V+DLES



181B0795 [🔗](#)
OPT-B1-V+DLDE:6 programmableDI/DO
 OPT-B1-V+DLDE



181B0796 [🔗](#)
OPT-B4-V+DLDE:AI,2AO(mA,isol),+24V/EXT
 OPT-B4-V+DLDE



181B0797 [🔗](#)
OPT-B5-V+DLES:3RO(NO)
 OPT-B5-V+DLES



181B0798 [🔗](#)
OPT-B5-V+DLDE:3RO(NO)
 OPT-B5-V+DLDE



181B0311 [🔗](#)
OPT-BH-V:3 temp meas channels
 OPT-BH-V

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**181B0310** [🔗](#)**OPT-BF-V:**
OPT-BF-V**181B0450** [🔗](#)**OPT-BJ-V:**
OPT-BJ-VImage
coming
soon**181B4132** [🔗](#)**OPT-E2-V:RS485 (Modbus/N2)**
OPT-E2-V**181B1485** [🔗](#)**OPT-C4-V+DNOT:LonWorks**
OPT-C4-V+DNOTImage
coming
soon**141F4277** [🔗](#)**AS-interface Fieldbus Option, OPT-BK-V**
OPT-BK-V**181B1482** [🔗](#)**OPT-BJ-V+DLES:**
OPT-BJ-V+DLES**181B2155** [🔗](#)**OPT-BJ-V+DLFI:**
OPT-BJ-V+DLFI**181B0800** [🔗](#)**OPT-BJ-V+DLDE:**
OPT-BJ-V+DLDE**181B0316** [🔗](#)**OPT-C4-V:LonWorks**
OPT-C4-VImage
coming
soon**181B3273** [🔗](#)**OPT-F5-V:**
OPT-F5-V**For more information, please use this link to visit the product page on Danfoss Product Store** [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

Image coming soon

181B4135 [🔗](#)
OPT-E8-V:RS485 with Sub-D9
 OPT-E8-V

Image coming soon

181B2164 [🔗](#)
OPT-E9-V+DNOT:2-port ethernet
 OPT-E9-V+DNOT



181B1488 [🔗](#)
OPT-E5-V+DNOT:PROFIBUS DP with Sub-D9
 OPT-E5-V+DNOT



181B0492 [🔗](#)
OPT-E9-V:2-port ethernet
 OPT-E9-V



181B0330 [🔗](#)
OPT-F4-V:
 OPT-F4-V



181B0329 [🔗](#)
OPT-F3-V:
 OPT-F3-V



181B0327 [🔗](#)
OPT-E6-V:CANopen
 OPT-E6-V



181B0326 [🔗](#)
OPT-E5-V:PROFIBUS DP with Sub-D9
 OPT-E5-V



181B0076 [🔗](#)
MR6 IP54 -kit
 VACON-ENC-IP54-MR06

Image coming soon

181B3003 [🔗](#)
VACON100 FLOW Application manual (10pcs)
 DOC-APP100FLOW-10+DLUK

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

Image
coming
soon**141F4210** [🔗](#)**VACON-DEM-0100-1L-2-CASE democase**

VACON-DEM-0100-1L-2-CASE

Image
coming
soon**181B5386** [🔗](#)**OPT-B9-V+DNOT:1RO(NO),5pcs of 41-240VAC**

OPT-B9-V+DNOT

Spare Parts

**181B1401** [🔗](#)**Discharging resistor assembly 48k 1 mm**

SPR-ELE15323

**181B2115** [🔗](#)**Skiip 38AC176V1 1700V 100A**

SPR-ELE14908

**181B2114** [🔗](#)**Skiip 28ANB18V1**

SPR-ELE14907

**181B1100** [🔗](#)**Terminal connector kit Vacon100**

SPR-ELE02023

**181B1093** [🔗](#)**Control flat cable MR06**

SPR-ELE01784

**181B1160** [🔗](#)**DC capacitor 700uF 800V**

SPR-ELE08058

**181B1159** [🔗](#)**DC capacitor 500uF 800V**

SPR-ELE08057

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



181B1158 [🔗](#)
EMC jumper 10pcs
SPR-ELE08056



181B1157 [🔗](#)
MR Ground Fault Transformer Current Sens
SPR-ELE08037



181B1053 [🔗](#)
MR06 Grounding plate+connector cover kit
SPR-MEC08055



181B1049 [🔗](#)
Internal fan
SPR-MEC00978



181B1175 [🔗](#)
"MR06 Accessories kit, inch"
SPR-MEC02005

Image coming soon

181B1172 [🔗](#)
"MR06 Accessories kit, metric"
SPR-MEC01799



181B1207 [🔗](#)
"MR06 Gland plate kit IP54, inch"
SPR-MEC08051



181B1204 [🔗](#)
"MR06 Gland plate kit IP54, metric"
SPR-MEC08048



181B1201 [🔗](#)
"MR06 Gland plate kit IP21, inch"
SPR-MEC08044



181B1198 [🔗](#)
"MR06 Gland plate kit IP21, metric"
SPR-MEC08040

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



181B2354 [🔗](#)
Fuse switch OS63030P
SPR-ELE13938



181B2288 [🔗](#)
Terminal block, 3-pole, 120A, 800V, mar
SPR-MEC14910



181B2286 [🔗](#)
DC-link capacitor 300 uF 1100 VDC 690VAC
SPR-ELE14773



181B0641 [🔗](#)
Control board MC04
SPR-CMB06634



181B0928 [🔗](#)
Rectifier kit Gen2 MR06
SPR-ELE07938



181B0916 [🔗](#)
Diode thyristor module SKKH 162/18E
SPR-ELE14690



181B0808 [🔗](#)
Main terminals MR06
SPR-MEC00982



181B0764 [🔗](#)
Main fan MR08 48VDC
SPR-MEC01861



181B0884 [🔗](#)
Power Board 61A 500V MR06 -empty
SPR-CMB04711-EMPTY



181B0385 [🔗](#)
Main fan MR06
SPR-MEC00980

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



181B0378 [🔗](#)
Control unit V100 (MC04 w/o I/O board)
 SPR-CMB06633



181B0495 [🔗](#)
IGBT kit Gen2 MR06
 SPR-ELE07879



181B1118 [🔗](#)
Main Cover MR06 IP21 Dark Grey, NCS 7010
 VACON-SPR-MEC01964



181B1119 [🔗](#)
Main Cover MR06 IP54 Dark Grey, NCS 7010
 VACON-SPR-MEC01965



181B1122 [🔗](#)
MR06 HVAC/FLOW/100 Main cover assembly,
 VACON-SPR-MEC01979-HVAC



181B2197 [🔗](#)
61A 500V Gen2 MR06 Power Board
 SPR-CMB04711+AMPV0038-5+MODX1V001+DBIN-R00+LS50+LSSI



181B1920 [🔗](#)
Main Cover IP54 MR06 Dark Grey
 VACON-SPR-MEC01965-HVAC



181B1919 [🔗](#)
Main Cover IP21 MR06 Dark Grey
 VACON-SPR-MEC01964-HVAC



181B1570 [🔗](#)
Power board 61A 500V MR06
 SPR-CMB04711-FLOW+AMPV0061-5+MODX2V001+DBNO-R00+LS60+LSSI



181B2639 [🔗](#)
61A 500V Gen2 MR06 Power Board
 SPR-CMB04711-HVAC+AMPV0061-5+MODX2V001+DBNO-R00+LS50+LSSI

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



181B2636 [🔗](#)

61A 500V Gen2 MR06 Power Board

SPR-CMB04711-HVAC+AMPV0038-5+MODX1V001+DBNO-R00+LS50+LSSI



181B2635 [🔗](#)

61A 500V Gen2 MR06 Power Board

SPR-CMB04711-FLOW+AMPV0061-5+MODX2V001+DBNO-R00+LS50+LSSI



181B2634 [🔗](#)

61A 500V Gen2 MR06 Power Board

SPR-CMB04711+AMPV0061-5+MODX2V001+DBIN-R00+LS50+LSSI



181B3055 [🔗](#)

Power Board 61A 500V MR06 Gen2

SPR-CMB04711-FLOW+AMPV0038-5+MODX1V001+DBNO-R00+LS50+LSSI



181B3729 [🔗](#)

Measurement board Vacon 200/500/600/690V

SPR-CMB15267+AMPV0062-6+MODX2V001+DBNO-R02+LS60+LSUS

Image coming soon

181B4121 [🔗](#)

Measurement boards MR11 MR12, programmed

SPR-CMB33055+AMPV0920-5+MODX2V001+DBIN-R00+LS50+LSSI



181B4122 [🔗](#)

Power Board 34A 690V MR6

SPR-CMB14772-FLOW+AMPV0027-6+MODX1V001+DBIN-R02+LS60+LSUS

Image coming soon

181B4123 [🔗](#)

Measurement boards MR11 MR12, programmed

SPR-CMB33055+AMPV0920-5+MODX2V001+DBNO-R00+LS50+LSSI



181B4098 [🔗](#)

Measurement board 500/690V MR10

SPR-CMB21899+AMPV0590-5+MODX2V001+DBNO-R00+LS60+LSSI

Image coming soon

181B4101 [🔗](#)

Measurement boards MR11 MR12, programmed

SPR-CMB33055+AMPV1180-5+MODX2V001+DBNO-R00+LS60+LSSI

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

Image
coming
soon**181B4103** [🔗](#)**Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV1180-5+MODX2V001+DBIN-R00+LS50+LSSI

**181B4307** [🔗](#)**Power Board 34A 690V MR6**

SPR-CMB14772+HVAC+AMPV0018-6+MODX1V001+DBIN-R00+LS50+LSSI

**181B3429** [🔗](#)**Power Board 38-61A 500V for MR06 Gen2**

SPR-CMB04711-FLOW+AMPV0046-5+MODX1V001+DBNO-R00+LS50+LSSI

**181B4729** [🔗](#)**Measurement board MR09B MR10, programmed**

SPR-CMB21899+AMPV0520-5+MODX2V001+DBNO-R00+LS50+LSSI

**181B4770** [🔗](#)**Measurement board Vacon 200/500/600/690V**

SPR-CMB15267-FLOW+AMPV0144-7+MODX1V001+DBNO-R00+LS50+LSSI

**181B4866** [🔗](#)**Measurement board V100, pre-programmed**

SPR-CMB29585+AMPVXXXX-7-X1-B

**181B4865** [🔗](#)**Measurement board V100, pre-programmed**

SPR-CMB29585+AMPVXXXX-5-X2-B

**181B4864** [🔗](#)**Measurement board V100, pre-programmed**

SPR-CMB29585+AMPVXXXX-5-X1-B

**181B4893** [🔗](#)**Measurement board Vacon 200/500/600/690V**

SPR-CMB15267-FLOW+AMPV0041-6+MODX2V001+DBIN-R00+LS50+LSSI

Image
coming
soon**181B5064** [🔗](#)**Control cover semi-matt for MR09**

VACON-SPR-MEC02014

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

Image
coming
soon**181B5303** **Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV0730-5+MODX1V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5417** **Miniature circuit breaker 2A 1P NAM**

SPR-ELE25089

Image
coming
soon**181B5418** **Miniature circuit breaker 6A 1P NAM**

SPR-ELE25087

Image
coming
soon**181B5425** **Modular socket 15A 125VAC 1P NAM**

SPR-ELE25093

Image
coming
soon**181B5428** **Measurement board 240/500V MR7-9, prog**

SPR-CMB01790-HVAC+AMPV0261-5+MODX1V001+DBNO-R00+LS50+LSSI

**181B5438** **Accessories bag with ext. box, 2-cabling**

SPR-MEC41716

Image
coming
soon**181B5445** **Measurement board 240/500V MR7-9, prog**

SPR-CMB01790+AMPV0205-5+MODX1V001+DBNO-R00+LS50+LSSI

**181B5470** **Cable gland plate IP54 for MR07, metric**

SPR-MEC44149

Image
coming
soon**181B5489** **Plate heat exchanger, type:M3-FG-70PL**

SPR-SOL44167

Image
coming
soon**181B5490** **Regulating valve actuator + 24VDC-module**

SPR-SOL44168

For more information, please use this link to visit the product page on Danfoss Product Store 

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



x6

181B5756 [🔗](#)**Filter mat 270x270mm (incl. 6 pcs)**

SPR-MEC43925



x6

181B5755 [🔗](#)**Filter mat 85x85mm (incl. 6 pcs)**

SPR-MEC43915

Image
coming
soon**181B5775** [🔗](#)**Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV1040-5+MODX2V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5786** [🔗](#)**Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV0820-7+MODX1V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5788** [🔗](#)**Regulating 3-way valve DN32**

SPR-SOL44682

Image
coming
soon**181B5792** [🔗](#)**Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV0650-5+MODX1V001+DBNO-R00+LS50+LSSI

**181B5815** [🔗](#)**Main fan assembly MR9**

SPR-ELE44150

**181B5816** [🔗](#)**Main fan with power assembly MR9**

SPR-ELE44935

**181B5828** [🔗](#)**Charging Switch INU-FI9-FI10-V2**

65-ELE43838-1194X2

**181B5831** [🔗](#)**IGBT and driver board assy 690V MR09b**

65-ELE38906-117UHW

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

**181B5830** [🔗](#)**Brake IGBT and driver assy 690V MR09b**

65-ELE38905-117UHV

**181B5845** [🔗](#)**Measurement board Vacon 200/500/600/690V**

SPR-CMB15267+AMPV0144-7+MODX1V001+DBNO-R00+LS50+LSSI

**181B0275** [🔗](#)**DC-power supply**

STL-EST09693

**181B0861** [🔗](#)**Software service kit for Vacon100**

STL-EST10606

Image
coming
soon**181B5864** [🔗](#)**Powerboard 16-31A 500V for MR5 Gen3**

SPR-CMB33714-FLOW+AMPV0031-5+MODX2V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5865** [🔗](#)**Powerboard 16-31A 500V for MR5 Gen3**

SPR-CMB33714+AMPV0031-5+MODX2V001+DBIN-R00+LS50+LSSI

Image
coming
soon**181B5872** [🔗](#)**Measurement boards MR11 MR12, programmed**

SPR-CMB33055+AMPV0820-5+MODX2V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5880** [🔗](#)**Measurement board MR09B MR10, programmed**

SPR-CMB21899+AMPV0416-7+MODX1V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5897** [🔗](#)**Measurement board 240/500V MR7-9, prog**

SPR-CMB01790-FLOW+AMPV0072-5+MODX1V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5902** [🔗](#)**Measurement board Vacon 200/500/600/690V**

SPR-CMB15267-FLOW+AMPV0052-7+MODX2V001+DBNO-R00+LS50+LSSI

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

Image
coming
soon**181B5903** [↗](#)**Measurement board 240/500V MR7-9, prog**SPR-CMB01790+AMPV0170-2+MODX1V001+DBNO-R00+LS60+LSSI

Image
coming
soon**181B5908** [↗](#)**Shipping box inc. dampers size 4 (4 pcs)**SPR-MEC46233

Image
coming
soon**181B5909** [↗](#)**Shipping box inc. dampers size 5 (4 pcs)**SPR-MEC46234

Image
coming
soon**181B5910** [↗](#)**Shipping box inc. dampers size 6 (4 pcs)**SPR-MEC46235

Image
coming
soon**181B5911** [↗](#)**Shipping box inc. dampers size 7 (4 pcs)**SPR-MEC46236

Image
coming
soon**181B5912** [↗](#)**Shipping box inc. dampers size 8 (4 pcs)**SPR-MEC46237

Image
coming
soon**181B5948** [↗](#)**Measurement board 105-310A 240/500V MR7-**SPR-CMB01790+AMPV0105-5+MODX2V001+DBNO-R00+LS50+LSSI

Image
coming
soon**181B5950** [↗](#)**Thermal paste Wacker P12, 90ML**STL-MST46417

Image
coming
soon**181B5951** [↗](#)**Thermal paste Dowsil TC-6000HP, 1kg**STL-MST46857

For more information, please use this link to visit the product page on Danfoss Product Store [↗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1131** [🔗](#)**DrivePro ExWarr Work Shop PG04 30 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1134** [🔗](#)**DrivePro ExWarr Work Shop PG04 48 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1135** [🔗](#)**DrivePro ExWarr Work Shop PG04 54 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1137** [🔗](#)**DrivePro ExWarr Work Shop PG04 66 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1138** [🔗](#)**DrivePro ExWarr Work Shop PG04 72 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1136** [🔗](#)**DrivePro ExWarr Work Shop PG04 60 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1130** [🔗](#)**DrivePro ExWarr Work Shop PG04 24 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1132** [🔗](#)**DrivePro ExWarr Work Shop PG04 36 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1133** [🔗](#)**DrivePro ExWarr Work Shop PG04 42 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1034** [🔗](#)**DrivePro ExWarr Onsite PG04 48 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1031** [🔗](#)**DrivePro ExWarr Onsite PG04 30 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1032** [🔗](#)**DrivePro ExWarr Onsite PG04 36 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1035** [🔗](#)**DrivePro ExWarr Onsite PG04 54 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1033** [🔗](#)**DrivePro ExWarr Onsite PG04 42 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1030** [🔗](#)**DrivePro ExWarr Onsite PG04 24 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1038** [🔗](#)**DrivePro ExWarr Onsite PG04 72 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1036** [🔗](#)**DrivePro ExWarr Onsite PG04 60 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1037** [🔗](#)**DrivePro ExWarr Onsite PG04 66 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1303** [🔗](#)**DrivePro Start-Up unit pre-order small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

**130R1313** [🔗](#)**DrivePro Start-Up 1 day on-demand small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1312** [🔗](#)**DrivePro Start-Up 1 Day Pre-order small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

**130R1304** [🔗](#)**DrivePro Start-Up unit on-demand small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**135N2219** [🔗](#)**70-AB3L00615W06B521BM26-00062115**

Frequency converter
 VACON100-3L-0061-5+SRBT+IP54+FBIE
 VACON 100 Industrial
 380-500 Vac, 61 Amp, IP54/NEMA12
 Graphical Keypad MK01
 C2 Commercial&Industry Environ
 B Slot: F3,3 Relay board
 C Slot: No board
 D Slot: No board
 E Slot: No board
 Fieldbus: IndEth (ProfinetIO, EthernetIP)
 Manual: English
 Frame 06
 Other options according to Model code

Model code: VACON100-3L-0061-5+SRBT+IP54+FBIE

VACON® 100 AC drives are ideal for saving energy, optimizing process control and improving productivity. They are designed for multi-purpose use while remaining easy to install, easy to commission and easy to operate.

The variants VACON® INDUSTRIAL and VACON® FLOW are available in power range 0.55-800 kW, voltage range 208-690 V, and protection ratings IP00, IP21/UL Type 1 and IP54/UL Type 12.

Image
coming
soon

130R1380 [🔗](#)**DrivePro Start-Up ½ day pre-order small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

General Terms and Conditions of Delivery and Warranty apply.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

Image
coming
soon**130R1381** **DrivePro Start-up ½ day on-demand small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

General Terms and Conditions of Delivery and Warranty apply.

For more information, please use this link to visit the product page on Danfoss Product Store 

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.